

These controllers are using state of the art wireless technology. Therefore they are to be treated with care. Under no conditions are you to attempt to repair or alter the configuration of the control. The controller is to be returned to the Main Office after each use. Although this may seem an inconvenience to you, the condition and security of this is of paramount concern to all of our users. Your cooperation is appreciated.

**Off/On power switch is located at left rear of control.**

**To set the time:**

**PRESS CLOCK SET, USE THE NUMBER PAD TO ENTER THE DESIRED TIME. TIME IS A 4 DIGIT ENTRY. SO FOR SINGLE MINUTES YOU MUST ENTER ZERO FIRST. HIT ENTER TO INPUT THE TIME.**

The toggle switch labeled "**Time In**" is used to start and stop the clock during play.

**To enter a MINOR penalty:**

**PRESS HOME OR VISITOR PENALTY AS APPROPRIATE; PRESS THE +1 KEY (IF A PLAYER RECEIVES TWO BACK-TO-BACK PENALTIES, YOU CAN PRESS ANOTHER OF THE + KEYS TO ADD TWO PENALTY TIMES TOGETHER.**

**AT PLAYER# PROMPT, ENTER THE PLAYER NUMBER ON THE NUMERIC KEYPAD AND THEN PRESS ENTER. If you hit enter prior to entering a player number a bell will sound and the display will read "No penalty found". You will need to re-enter the information from the beginning.**

**Stacking Penalties**

The scoreboard can store up to three additional penalties per team in memory.

If you correct the game clock during a game period when penalty times are entered, the prompt will read:  
**CORR.PENALTY? Y/N**

Press SHIFT + NO to accept the current times.

Press SHIFT + YES if you want to correct the penalties that are actively counting. If you press SHIFT + YES, the controller prompts you to enter new times for each counting penalty. Enter the new time for each penalty as prompted, pressing ENTER after each.

**Canceling Individual Penalties**

1. Press **HOME PENALTY** or **VISITOR PENALTY**.
2. Press the **CLR** key to clear the penalty.
3. The control prompts you for a player number. **Enter the player number and press ENTER.** The control then displays the time of penalty in memory.

OR

Use the numeric keypad to key in a different amount of time.

4. Press ENTER.

**Entering Goals**

Press **HOME (VISITOR) SCORE** and the **+1** key.

**Entering the Period**

Press **PERIOD** and the **+1** key.