

Tewksbury Elementary school Score board info

Start of game

Under the back right on the orange box is the key in a box. Open the unit and put the key back.

Disconnect the wire running from solar panel to the solar charger. Then remove the black prong and remove the red prong in this order and place the charger on the tray. Connect the red circular connector to the positive side of battery (opposite from where black line is already connected) that is dangling and tighten down with the bolt. The scoreboard should now be lit up. Attach the black prong to the negative side and the red prong to the positive side in this order. Plug in the solar charger to the wire that connects to the solar panel (be sure to connect the right port). The solar charge should show a yellow light. Remove the remote, turn on with dial at the bottom and make sure it turns on and is able to change things on the board (runs,outs etc). If it doesn't turn on or it turns on but you see nothing on the screen then or it won't change the board then shut the remote off and put new batteries in and try again.

****ONLY USE BATTERIES IN the box NEVER bring your own batteries.** If it still doesn't work you will have to play without the board and call Garrett DelGrande 732-236-9948. Follow shut down procedures below. If the remote works then lock the unit while the game is on remember to put the key back.

Shut down.

Open the box. Turn the remote off and place back in box. Disconnect the wire that connects the solar panel to the charger. Remove the black prong from the negative side and the red prong from the positive side in this order and set the prongs down (do not let the prongs touch one another while one end is still connected to the battery. Remove the red circular connector from the positive side and leave dangle. This shuts off the board. Attach the black prong to the negative side then the red prong to the positive side in this order. Plug in the solar panel wire to the solar charger (correct port). The charger light (yellow) should light up. Lock the box and put the key back.